


GUIDE FOR PRINTING ON WINDOWS

Install Profiles on Windows ---> c:/windows/system32/spool/drivers/color

PHOTOSHOP SETTINGS



1) Color Handling - Photoshop Manages Colors


2) Printer Profile

LS_FrontlitBannerMatt430_720_E11880_MK.icm

3) Rendering Intent - Relative Colorimetric

4) Black Point Compensation activated

DRIVER SETTINGS



1) Media Type

Doubleweight Matte Paper

2) Print Quality - Quality 2 (720x720ppp)

3) Mode - Custom

4) No Color Adjustment

5) Paper Config - Color Density (-15%)




EPSON SP11880

LS FRONTLIT BANNER MATT 430g

GUIDE FOR PRINTING ON MAC OS X

Install Profiles on Mac OS X ---> Macintosh HD > User > Library > ColorSync > Profiles

PHOTOSHOP SETTINGS



1) Color Handling - Photoshop Manages Colors


2) Printer Profile

LS_FrontlitBannerMatt430_720_E11880_MK.icm

3) Rendering Intent - Relative Colorimetric

4) Black Point Compensation activated

DRIVER SETTINGS



1) Media Type

Doubleweight Matte Paper

2) Color Mode - No Color Adjustment

3) Print Quality - Quality 2 (720x720ppp)

Paper Config - Color Density (-15%)